

Deep Learning for Recognizing Human Activities using Motions of Skeletal Joints

This page describes about the detail parameters for creating the datasets that presented in the paper with the title "Deep Learning for Recognizing Human Activities using Motions of Skeletal Joints" which has been submitted to IEEE Transaction on Consumer Electronic.

The proposed system used two types of inputs Color Skeleton Motion History Image (Color Skl-MHI) and Relative Joint Image (RJI) for training in deep convolutional neural network trained by using Matcaffe framework for the recognition of human daily activity using depth sensor.

The experimental datasets are created based on the data provided by UTKinect Action3D and CAD60 dataset. Because of the skeletal structure given by 2 datasets are different, we separately perform features extraction (Color Skl-MHI and RJI), training and testing on each dataset but the algorithms that have been used are the same.

Content:

- 1. Downloading the Datasets**
- 2. Creation of Color Skl-MHI and RJI Dataset on UTKinect Action-3D Dataset**
- 3. Creation of Color Skl-MHI and RJI Dataset on CAD60 Dataset**
- 4. Separation of Training and Test Data**
- 5. Creation of hdf5 database on UTKinect Action-3D Dataset**
- 6. Creation of hdf5 database on CAD60 Dataset**
- 7. Training 3D-DCNN on UTKinect Action-3D Dataset**
- 8. Training 3D-DCNN on CAD60 Dataset**
- 9. Testing 3D-DCNN on UTKinect Action-3D Dataset**
- 10. Testing 3D-DCNN on CAD60 Dataset**

1. Downloading the Datasets

1.1 UTKinect Action3D Dataset

UTKinect Action3D dataset can be downloaded at: <http://cvrc.ece.utexas.edu/KinectDatasets/HOJ3D.html>. After downloading, copy the "joints" folder into the `datasets\UTKinect\` folder.

Then, separate `actionLabel.txt` file into 20 files (`s01_e01.txt`, `s01_e02.txt`, etc...) where each file contains (action: start_Frame end_Frame) information and copy to `datasets\UTKinect\actions\` folder.

1.2 CAD60 Dataset

CAD60 dataset can be downloaded at: <http://pr.cs.cornell.edu/humanactivities/data.php>. After downloading the dataset, copy the skeleton coordinate file .txt under the "data1, data2, data3 and data4" folders into the **datasets\CAD60** folder. Modify each txt file by adding the action number in front of the file. (For example: **0_0512172825.txt** which contain skeletal joints coordinates of action "still"). The number for each action is as follow:

- | | |
|---------------------------|---------------------------|
| 0. Still | 7. cooking(chopping) |
| 1. rinsing mouth | 8. cooking(stirring) |
| 2. brushing teeth | 9. talking on couch |
| 3. wearing contact lenses | 10. relaxing on couch |
| 4. talking on phone | 11. writing on whiteboard |
| 5. drinking water | 12. working on computer |
| 6. opening pill container | |
-

2. Creation of Color Skl-MHI and RJI Dataset on UTKinect Action-3D Dataset

For converting the 3D joint coordinate of URKinect Action-3D dataset, we need to download "Kin2" from this URL: <https://github.com/jrterven/Kin2> and copy into the "tools" folder. Then, the creation of Color Skl-MHI and RJI Dataset on UTKinect Dataset can be done by running **experiments\UTKinect\Create_ColorSklMHI_RJI_UTKinect.m** file and the extracted Color Skl-MHI and RJI of UTKinect dataset will be stored in **ColorSklMHI_RJI_UTKinect.mat** which can be downloaded at:

https://drive.google.com/file/d/1pOg_ABh7JaqBzGEQ8BtYa3CVoEIAtwPn/view?usp=sharing

3. Creating Color Skl-MHI and RJI Dataset on CAD60 Dataset

The creation of Color Skl-MHI and RJI Dataset on CAD60 Dataset can be done by running **experiments\CAD60\Create_ColorSklMHI_RJI_CAD60.m** file and the extracted Color Skl-MHI and RJI of CAD60 dataset will be stored in **ColorSklMHI_RJI_CAD60.mat** which can be downloaded at:

<https://drive.google.com/file/d/1PdktPgnFGkYUktrXJjUfx-j0nGwbvyqY/view?usp=sharing>

4. Separation of Training and Test Data

For training and testing the proposed system using the method of "*Leave-One-Subject-Out-Cross-Validation*", we separate the training and test data according to leave-one-person-out rule.

4.1 Separation of Training and Test Data on UTKinect Action3D Dataset

UTKinect Action3D dataset include 10 subjects who performed the actions. Therefore, we performed 10 experiments by separating the training and testing data as follow:

Training People	Test Person
P2,P3,P4,P5,P6,P7,P8,P9,P10	P1
P1,P3,P4,P5,P6,P7,P8,P9,P10	P2
P1,P2,P4,P5,P6,P7,P8,P9,P10	P3
P1,P2,P3,P5,P6,P7,P8,P9,P10	P4
P1,P2,P3,P4,P6,P7,P8,P9,P10	P5
P1,P2,P3,P4,P5,P7,P8,P9,P10	P6
P1,P2,P3,P4,P5,P6,P8,P9,P10	P7
P1,P2,P3,P4,P5,P6,P7,P9,P10	P8
P1,P2,P3,P4,P5,P6,P7,P8,P10	P9
P1,P2,P3,P4,P5,P6,P7,P8,P9	P10

The separation of Training and Test Data on UTKinect Action3D dataset can be done by running `experiments\UTKinect\Separate_Person_UTKinect.m` file. After running program, all training and test data will be save into the `UTKinect_LOSOCV_Clip_ColorSkIMHI.mat` file.

4.2 Separation of Training and Test Data on UTKinect Action3D Dataset

CAD60 dataset include 4 subjects who performed the actions. Therefore, we performed 4 experiments by separating the training and testing data as follow:

Training People	Test Person
P2,P3,P4	P1
P1,P3,P4	P2
P1,P2,P4	P3
P1,P2,P3	P4

The separation of Training and Test Data on CAD60 dataset can be done by running `experiments\CAD60\Separate_Person_CAD60.m` file. After running program file, all training and test data will be save into the `CAD60_LOSOCV_Clip_ColorSkIMHI.mat` file.

5. Creation of hdf5 database on UTKinect Dataset

For training the 3D-DCNN, we need to create hdf5 database for each training and test set. The creation of hdf5 database on UTKinect Dataset can be done by running `experiments\UTKinect\Create_hdf5Database_ColorSkIMHI_RJI_UTKinect.m` file which will generate .h5 and .txt file for each training and test data. For creating the hdf5 database, we need to use the function "`store2hdf5.m`" provided in Matcaffe framework and copy into the same folder. Read and update some comments line for creating the hdf5 database for both Color Skl-MHI and RJI of UTKinect Action-3D dataset. We need to create 10 hdf5 database for each person. So, the total database files are $10 (.h5) \times 10 (\text{People}) = 100 \text{ files}$. For example:

- a. UTKinect_ColorSkIMHI_T15_NotP1
 - b. UTKinect_ColorSkIMHI_T15_P1
 - c. UTKinect_RJI_1_T15_NotP1
 - d. UTKinect_RJI_1_T15_P1
 - e. UTKinect_RJI_2_T15_NotP1
 - f. UTKinect_RJI_2_T15_P1
 - g. UTKinect_RJI_3_T15_NotP1
 - h. UTKinect_RJI_3_T15_P1
 - i. UTKinect_RJI_4_T15_NotP1
 - j. UTKinect_RJI_4_T15_P1
-

6. Creation of hdf5 database on CAD60 Dataset

For training 3D-DCNN, it needs to create hdf5 database for each training and test set. This can be done by running `experiments\CAD60\Create_hdf5Database_ColorSkIMHI_RJI_CAD60.m` file which will generate .h5 and .txt file for each trainig and test data. For creating the hdf5 database, we need to use the function "`store2hdf5.m`" provided in Matcaffe framework and copy into the same folder. Read and update some comments line for creating the hdf5 database for both Color Skl-MHI and RJI of CAD60 dataset. We need to create 10 hdf5 database for each person. So, the total database files are $10 (.h5) \times 4 (\text{People}) = 40 \text{ files}$. For example:

- a. CAD60_ColorSkIMHI_T15_NotP1
 - b. CAD60_ColorSkIMHI_T15_P1
 - c. CAD60_RJI_1_T15_NotP1
 - d. CAD60_RJI_1_T15_P1
 - e. CAD60_RJI_2_T15_NotP1
 - f. CAD60_RJI_2_T15_P1
 - g. CAD60_RJI_3_T15_NotP1
 - h. CAD60_RJI_3_T15_P1
 - i. CAD60_RJI_4_T15_NotP1
 - j. CAD60_RJI_4_T15_P1
-

7. Training 3D-DCNN on UTKinect Dataset

After creating the hdf5 database of Color Skl-MHI and RJI from the UTKinect Dataset, we can train 3D-DCNN for Color Skl-MHI and RJI by running the [experiments\UTKinect\Train_DCNN_ColorSklMHI_RJI_UTKinect.m](#) file. We need to train 5 caffemodels for each person as follow:

- a. UTKinect_ColorSklMHI_NotP1
- b. UTKinect_RJI_1_NotP1
- c. UTKinect_RJI_2_NotP1
- d. UTKinect_RJI_3_NotP1
- e. UTKinect_RJI_4_NotP1

Therefore, total trained models are 5×10 (people) = **50 caffemodels** which can download at: https://drive.google.com/file/d/1BOwAuIVsjsx57wmjvcwTbtOsXOq4_DLfW/view?usp=sharing

8. Training 3D-DCNN on CAD60 Dataset

After creating the hdf5 database of Color Skl-MHI and RJI from the CAD60 dataset, we can train 3D-DCNN for Color Skl-MHI and RJI by running the [experiments\CAD60\Train_DCNN_ColorSklMHI_RJI_CAD60.m](#) file. We need to train 5 caffemodels for each person as follow:

- a. CAD60_ColorSklMHI_NotP1
- b. CAD60_RJI_1_NotP1
- c. CAD60_RJI_2_NotP1
- d. CAD60_RJI_3_NotP1
- e. CAD60_RJI_4_NotP1

Therefore, total trained models are 5×4 (people) = **20 caffemodels** which can download at: https://drive.google.com/file/d/16Wxh8Cp03_nC7MbPiRMJRmtuGat5x2wv/view?usp=sharing

9. Testing 3D-DCNN on UTKinect Action-3D Dataset

Trained 3D-DCNN on UTKinect Action-3D dataset can be tested by running the [experiments\UTKinect\Test_DCNN_ColorSklMHI_RJI_UTKinect.m](#) file. For calculating the overall accuracy, please change person id and caffemodels.

10. Testing 3D-DCNN on CAD60 Dataset

Trained 3D-DCNN on CAD60 dataset can be tested by running the [experiments\CAD60\Test_DCNN_ColorSklMHI_RJI_CAD60.m](#) file. For calculating the overall accuracy, please change person id and caffemodels.
